

**To convert from Inches of Mercury Absolute (HgA) to Inches of Mercury Gauge (HgV) to Torr (Torr) and Pounds per Square Inch Absolute (PSIA)**

To convert from Inches of Mercury Absolute to others      **1** "HgA      **28.92** "HgV      **25** Torr      **0.49** PSIA

**To convert from Inches of Mercury Gauge (HgV) to Inches of Mercury Absolute (HgA) to Torr (Torr) and Pounds per Square Inch Absolute(PSIA)**

To convert from Inches of Mercury Gauge (HgV) to others      **1.00** "HgV      **28.92** "HgA      **735** Torr      **14.21** PSIA

**To convert from Torr (Torr) to Inches of Mercury Gauge (HgV) to Inches of Mercury Absolute (HgA) and Pounds per Square Inch Absolute (PSIA)**

To convert from Torr (Torr) to others      **1** Torr      **29.88** "HgV      **0.04** "HgA      **0.02** PSIA

**To convert from Pounds per Square Inch Absolute (PSIA) toTorr (Torr) to Inches of Mercury Gauge (HgV) to Inches of Mercury Absolute (HgA)**

To convert from Pounds/Square Inch Absolute (PSIA) to others      **1.00** PSIA      **52** Torr      **27.88** "HgV      **2.04** "HgA

Only fill in yellow sections.

The program automatically calculates the green sections. You do nothing.

The program caclulates the final answers in red. You do nothing.

Never type in green or red cells

CONVERSION CHART			
PSIA	"HgV	"HgA	Torr
14.7	0	29.92	760
13.7	2	27.92	709
12.2	5	24.92	633
9.8	10	19.92	506
7.3	15	14.92	379
5.9	18	11.92	303
4.9	20	9.92	252
3.9	22	7.92	201
2.4	25	4.92	125
0.9	28	1.92	49
0.5	29	0.92	23
0	29.92	0	0

